

Sunshade hook repair

Open both rear windows to the lowest position. From either side, reach in and pull out the sunshade so that you have access to the end cap where the broken piece is.

1. Carefully pull the end plug out as shown below. It is plastic so it will scratch.



Once you have the plug out you can remove the small piece of plastic that once was the original hook. The result should look like this.



2. Press in the large barrel of the new hook into the opening and replace the plug noting that the slots in the plug should line up with the hook as it is pushed back into place. Repeat for the other side.



You are finished! Do not drive with rear windows open and the sunshade out, you will destroy the headliner hooks and these have no replacement yet, I'm working on it!

Enjoy!

**Mwrench
Ed Raether
(408) 354-0123
ed@mwrench.com**